

Please read these instructions thoroughly, regardless of how you intend to carry the knife. If you are using the sheath with the MOLLE locks (Fig. 1) then the rubber washer goes between the MOLLE Lock and the sheath. Compress it to about 1/2 of its thickness when you tighten. DO NOT use the rubber washers with the optional MOLLE back (Fig. 2). ONLY carry in inverted mode (upside down) when using the MOLLE back and extra retentions (Velcro strap, pommel cover) included on the MOLLE back. Boot clip is for non-secure IWB or belt carry only!

